




Adsorption dryer  
ecodry  
K-MT 1-8



Operating instructions

Revision 05—2006/EN

CE 0525

# Declaration of Conformity

**ZANDER Aufbereitungstechnik GmbH & CO KG**

**Im Teelbruch 118**

**D – 45219 Essen Kettwig**

hereby declares with sole responsibility, that the products

**compressed air adsorption dryer**

**series K-MT 1–8**

**assembly type: assembly acc. to Art. 3 No. 2.2,**

which this declaration refers to, conform to Directive **97/23/EC** and were subjected to a conformity assessment according to Annex III (Module A).

The assembly consists of pressure appliances according to the classification list (attached to the technical documentation provided by the manufacturer).

The following standards / technical specifications were used:

- harmonized standards: DIN EN 292-1, DIN EN 292-2, DIN EN 1050, DIN EN 50081, DIN EN 50082, DIN EN 60204

The following other EC directives were used:

- 98/37/EC
- 89/336/EEC
- 73/23/EEC

*Signature*



Dr. Walter Steudle  
Managing Director

# Machine passport

<b>Type designation</b>	<b>K-MT</b>
Order no.	
Project no.	
Build no.	
Year of manufacture	2006
Issue date of these operating instructions	2006-01 EN

It is the responsibility of the owner,

- to enter for the first time any appliance data not stated above,
- to keep these appliance data up to date.

The above-stated appliance data provide for a clear identification of the dryer and its components, and significantly facilitate any service measures.

Further important data on the dryer such as the details on the permissible operating pressure and the electrical connection are found on the type plate (for position of the type plate see page 9).

# Table of contents

<b>General information .....</b>	<b>6</b>
Manufacturer's details .....	6
Details on the dryer .....	7
About these operating instructions.....	8
<b>For your own safety .....</b>	<b>9</b>
Signs and hazard areas on the dryer.....	9
Intended use of the dryer.....	11
General safety notes .....	11
Safety notes on specific operating phases.....	12
<b>Technical product description .....</b>	<b>15</b>
Summary drawing .....	15
Function description .....	15
Available options .....	18
<b>Transportation, installation and storage.....</b>	<b>20</b>
Information on transportation packaging.....	20
What to do in the case of transport damage occurring?.....	20
Transporting and installing the dryer.....	21
Storing the dryer.....	23
<b>Installation.....</b>	<b>24</b>
Preconditions for installation.....	24
Connect piping .....	24
Installing the electrical connection .....	25
Mount mufflers to K-MT 3-4 .....	27
<b>Start-up.....</b>	<b>28</b>
Requirements for initial start-up.....	28
Setting times of the operating phases.....	29
Overview of operating and control elements.....	29
Emergency shutdown .....	32
Start up dryer .....	32
Changing cycle mode (optional) .....	34
<b>Monitoring dryer operation.....</b>	<b>36</b>
With dewpoint-sensing control (optional).....	36
<b>Shutdown and restart dryer.....</b>	<b>37</b>
Emergency shutdown .....	37

Depressurising and shutting down the dryer .....	38
If work is to be carried out on the electrical system .....	38
Restart .....	38
<b>Maintenance and repair of the dryer .....</b>	<b>40</b>
Notes on maintenance .....	40
Regular maintenance intervals .....	41
Instructions for use of the dongle .....	42
Daily maintenance tasks .....	42
Weekly maintenance tasks .....	43
Monthly maintenance tasks .....	43
Maintenance work to be completed every 12 months .....	44
Maintenance work to be completed every 24 months .....	47
Maintenance work to be completed every 48 months .....	49
<b>Identify and eliminate faults .....</b>	<b>53</b>
Summary of faults .....	53
<b>Index .....</b>	<b>56</b>
<b>Annex with technical documentation .....</b>	<b>59</b>
Technical data .....	60
Replacement and wear parts list .....	61
Logic control diagram .....	62
Flow diagram .....	64
Dimensional drawing .....	65

## General information

### Manufacturer's details

---

#### Name and address

<i>Zander</i> Aufbereitungstechnik GmbH & Co. KG	
Im Teelbruch 118	Postfach 185524
45219 Essen	45205 Essen
Telephone	++49 (0)2054/934-0
Telefax	++49 (0)2054/934-164
Internet:	<a href="http://www.zander.de">www.zander.de</a>
E-mail:	<a href="mailto:info@zander.de">info@zander.de</a>

#### Service and orders

##### **Service and spare part order**

Telephone ++49 (0)2054/934-180

Telefax ++49 (0)2054/934-117

You can also use these telephone numbers to order consumables such as desiccant etc. as well as spare parts. When ordering spare parts, always state the type and build no. of the dryer. Both are shown on the type plate of the dryer.

---

## Details on the dryer

---

### Standard equipment

Dryer, comprising

- 1 double-chamber hollow section vessel, filled with drying agent
- 1 upstream filter
- 1 downstream filter
- Muffler
- Control system

Associated documents

- Operating instructions (present)
- Technical documentation (see annex)
- Circuit diagrams (see separate document)

### Warranty notes

In the following cases, the warranty shall be void:

- If aggressive media in the compressed air and in the environment cause corrosion damage and functional faults on the dryer.
- If the dryer is used without prior approval and confirmation in writing by the manufacturer for purposes other than those specified in these operating instructions or contractually agreed.
- If preset parameters (e. g. on the control system etc.) are changed without prior approval and confirmation in writing by the manufacturer.
- If the dryer is transported or stored incorrectly.
- If the dryer is sited and installed incorrectly.
- If the dryer is repaired or maintained incorrectly.
- If the dryer is operated by personnel that does not have the requisite qualifications.
- If modifications are carried out on the dryer, the manufacturer did not approve that.

In the event of non-compliance the manufacturer will not accept any liability for any consequential damage whatsoever.

## About these operating instructions

---

These operating instructions contain basic information on the safe use of the dryer.

### Characters and symbols used

- ▶ Work steps that you have to carry out in the sequence stated are marked by black triangles.
- Lists are marked by a small box.

#### **Note:**

**These notes provide you with hints and information on the safe and efficient handling of machines and devices.**



#### **Warning!**

**These safety notes warn against damage to property and help you to avoid such damage.**



#### **Danger!**

**These danger notes with a grey background warn against personal injury and/or danger to life and limb; danger notes help you to avoid serious or life-threatening situations for yourself and/or third parties.**

### Target group of these operating instructions

These operating instructions are intended for all persons working on and using the dryer. We assume that all such persons are specialist personnel, e.g. fitters or electricians.

### Operating instructions: handling

These operating instructions must be continuously available at the site where the dryer is used. We recommend to prepare a copy and to keep the same in a safe and freely accessible place next to the dryer. Keep the original document in a safe place.

## For your own safety

The dryer has been built in accordance with the state of the art and the recognized technical safety regulations. Nevertheless, there is a risk of personal injury and damage to property when the dryer is used, if


- it is operated by non-qualified personnel,
- not used within its intended design specifications,
- is repaired or maintained incorrectly.

**Note:**

**For your own safety and to prevent machine damage, please note the information and safety notes in these operating instructions when working with the dryer.**


## Signs and hazard areas on the dryer

### Signs and labels



Please note these signs on the dryer. Keep them complete and always legible.

## Hazard areas on the dryer



Hazard area	Symbol in operating instructions
<p><b>Warning against hazardous electrical voltage</b></p> <p>Different parts of the dryer carry electrical current. These parts may be connected, opened, and maintained by authorized specialist personnel only.</p>	
<p><b>Warning against overpressure</b></p> <p>The entire dryer is under pressure. Before commencing any work, the plant must be depressurised.</p>	
<p><b>Warning against sudden air ejection</b></p> <p>When the hollow section vessels are depressurised, air flows suddenly out of the sound absorber.</p> <ul style="list-style-type: none"> <li>■ This causes a sudden loud cracking noise.</li> <li>■ Due to particles carried in the air flow, there is a very considerable risk of eye injury.</li> </ul> <p>When working on the dryer, always wear eye and ear protection equipment.</p>	
<p><b>Risk of skidding</b></p> <p>When emptying and filling the hollow section vessels with drying agent, there is a risk of skidding caused by spilt drying agent.</p>	

---

## Intended use of the dryer

---

The dryer is exclusively intended for drying compressed air. Depending on defined input conditions, it dries compressed air for industrial use.

The dryer is designed for compressed air, which is free from aggressive water, oil, and solid matter constituents.

As standard, the dryer is intended to be sited within a building and protected against the weather. When it is sited in the open air (option), the instructions on page 18 must be complied with.

The dryer may be operated only in accordance with the data on the type plate and in accordance with the contractual conditions.

## Suspected misuse

The dryer must not be misused as a climbing aid! Pipes, valves, and similar fittings have not been designed for such loads. They could fracture, tear off, or become damaged in another way.

---

## General safety notes

---



**For your own safety, when carrying out any work on the dryer comply with all applicable national safety regulations!**

## Personnel qualification

Only authorized and qualified specialist personnel may be tasked with the work on the dryer described in these operating instructions.

## Conversions and modifications

Without prior approval by the manufacturer, no conversions and modifications must be made to the dryer! Any non-approved modifications may restrict the operational safety of the dryer and cause damage to property or personal injury.

## Handling drying agents

The drying agents used do not pose any risk to health. However, when filling and emptying the hollow section vessels with drying agents, increased dust generation may occur. Please comply with the following instructions:

- When filling drying agents, wear a dust mask and eye protection!
- If a spillage occurs, any spilt drying agent must be taken up immediately. There is a risk of skidding!

## Safety notes on specific operating phases

---

### Transportation and siting

- During transportation all applicable national regulations for accident prevention must be complied with.

### Start-up



#### **Warning against sudden air ejection!**

**During expansion the pressure is released suddenly through the muffler:**

- A loud expansion noise is caused which may damage your hearing.
- Particles carried in the air can injure your eyes or skin.

**Always wear eye and ear protection, therefore, when you are in the vicinity of the dryer!**



#### **Hazard due to a sudden release of pressure!**

**Never remove any parts of the dryer, or manipulate the same in any way, for as long as the plant is still pressurised! A sudden escape of pressure may cause serious injuries.**

**Before carrying out any work on the dryer, first depressurise the plant.**

- Carry out all prescribed tests and checks.
- The factory settings on the control board in the switchbox must not be changed on any account without prior approval by the manufacturer.
- Before start-up, ensure that no tools or other foreign parts have been left lying in a part of the dryer where they might pose a hazard to the dryer being started up.

### Emergency shutdown

- In the event of an emergency, immediately close the compressed air supply line and set ON/OFF switch of the dryer to position 0 to disconnect it from the power supply. Afterwards depressurise the dryer (see also chapter , page 37).

### Monitor operation



#### **Warning against sudden air ejection!**

**During expansion the pressure is released suddenly through the muffler:**

- A loud cracking noise occurs which can injure your hearing.
- Particles carried in the air flow act like bullets and can injure your eyes or skin.

**Always wear eye and ear protection, therefore, when you are in the vicinity of the dryer!**

- Only operate the dryer within the permissible limits (see type plate). By operating the dryer in conditions that go beyond the defined values, the dryer is subjected to loads for which it has not been designed. This may cause functional defects.
- The more powerful the dryer is, the more noise may be generated during operation. Therefore, the operator must provide suitable protective equipment (e. g. ear protection).
- Check the dryer regularly for externally visible damage and defects. Any changes, even in its operating behaviour, must be reported immediately to the competent office or person.
- In the event of an emergency or if a safety-relevant disruption occurs (e.g. escaping compressed air, defective component), immediately close the compressed air supply line and set the ON/OFF switch of the dryer to 0 in order to disconnect it from the power supply. Afterwards depressurise the dryer (see also chapter , page 37). The unit may only be restarted after all defects have been eliminated.

## Maintenance of the dryer and fault removal



### **Hazard due to a sudden release of pressure!**

**Never remove any parts of the dryer, or manipulate the same in any way, for as long as the plant is still pressurised! A sudden escape of pressure may cause serious injuries.**

**Before carrying out any work on the dryer, first depressurise the plant.**

- Carry out maintenance work only when the plant has been shut down and depressurised!
- The factory settings on the control board in the switchbox must not be changed on any account without prior approval by the manufacturer.
- Bolt connections must be undone with care! Note ram pressure values! Otherwise emerging media may cause personal injury.
- Never use pipes and fittings as steps or holding points! The components might fracture, or the distortions which occur may cause internal damage on the dryer. There is a risk of injury by slipping off the components, components breaking off, and expanding compressed air!
- Never leave tools, loose parts or cloths at or on the dryer.
- Following maintenance work always test all flange and bolt connections for leak tightness and secure seating.
- Only use replacement parts that are suitable for the relevant function and meet the technical requirements stipulated by the manufacturer. This is always the case, if you use original replacement parts only.

## Disassembly and disposal



**Hazard due to a sudden release of pressure!**

**Never remove any parts of the dryer, or manipulate the same in any way, for as long as the plant is still pressurised! A sudden escape of pressure may cause serious injuries.**


**Before carrying out any work on the dryer, first depressurise the plant.**

- Dispose all parts of the dryer, the drying agent, and all other operating materials in an environmentally safe way and in accordance with all current statutory regulations. The waste code numbers of the drying agents can be obtained from the manufacturer (for the manufacturer's address see page 6).

# Technical product description

## Summary drawing

### Front view



## Function description

The dryer dries the compressed air supplied by the compressor and makes it available for industrial use.

Upstream filters clean the compressed air and remove dust, dirt, oil, and water droplets, before the compressed air reaches the dryer. Thus, an upstream filter is also used for extending the service life of the drying agent.


Downstream filters clean the compressed air from drying agent abrasions, before it is fed into the compressed air system.

The two chambers of the hollow section vessel contain an extremely porous drying agent by means of which humidity is removed from the compressed air and stored just as in a sponge. The stored humidity is then removed again from the drying agent and re-introduced into the ambient environment.

To this end, the two chambers alternate between different operating modes. Whilst in one vessel, compressed air is de-humidified (adsorption), in the other vessel the humid drying agent is prepared for another charge (regeneration). These two states, which run in parallel during compressed air preparation, are described below.

## Adsorption

Via a compressor, humid compressed air is supplied to the upstream filter. From here, the compressed air flows upwards through the absorption chamber, which is pressurised. In so doing, the drying agent dehumidifies the air. The dry compressed air is supplied to the pipe network via the downstream filter.



*Here, adsorption is shown in the left chamber.*

## Regeneration (running in parallel to the adsorption)

At the same time the other chamber is prepared for a renewed take-up of humidity. This process is called regeneration.

The regeneration is subdivided into three phases: expansion, dehumidification, and pressure build-up.


With the *dewpoint-sensing control* option, the regeneration phase is followed by a standby phase.

### Expansion phase

During the expansion phase the pressure in the right chamber is released via the muffler down to ambient pressure within just a few seconds. The outflow of the compressed air becomes noticeable due to a sudden powerful flow noise at the muffler.

### Dehumidification phase


Prior to being released into the pipe network, dried compressed air is bled by means of an orifice plate. This separate regeneration air flow is fed through the depressurised chamber. The humidity stored in the drying agent is taken up by the air flow and expelled into atmosphere via the muffler.



*Here, regeneration is shown in the right chamber.*

### Pressure build-up phase

After dehumidification the pressure in the regenerated hollow section vessel is built up to operating pressure, so that the switchover from regeneration to adsorption can take place at operating pressure level.



*Pressure build-up*

### Standby phase (only with the *dewpoint-sensing control option*)

When in standby phase, the fully regenerated chamber is ready for absorption operation. The system is switched to this chamber, as soon as the measured dewpoint at the compressed air outlet has reached the set dewpoint value for switchover.

## Switchover

When the drying agent in the adsorbing chamber has taken up a sufficient level of humidity, then the switchover between the vessels will be effected between the vessels. Following switchover, the above-described process is repeated, with the adsorption and regeneration now taking place in the respective different vessel.

## Available options

---

The following options are available for the dryer:

- Start-up device
- Outside installation
- Auxiliary heater
- Bypass line
- Signalling contacts of control system
- Compressor synchronisation
- Dewpoint-sensing control
- Pneumatic control
- Paint compatible design

### Start-up device

A start-up device basically consists of a pressure holding device, which is located at the rear of the dryer. The pressure holding device ensures that pressure can build up in the dryer and adsorption take place.

It is always required when an empty compressed air reservoir or an empty compressed air system must be filled downstream of the dryer (e.g. following weekend shutdowns and when the pressure in the compressed air system can frequently drop below the stated operating pressure).

The start-up device cannot be combined with the regeneration gas return line option.

### Outside installation

As standard, the dryer is not suitable for outside installation, as its function and service life is influenced by the following factors:

- Environmental humidity due to rain (or other deposit)
- Corrosion caused by environmental humidity or a salt-containing environment
- Freezing of valves, cocks, flaps, and other components at low temperatures

Therefore, a planned outside installation must always be discussed in advance with the manufacturer to allow specific technical design measures to be provided for the installation location.

### Auxiliary heater

For installation sites with temperatures under +1 °C (33,8 °F), the wet side of the dryer must be equipped with an auxiliary heater to prevent valves, cocks, flaps, and other components from freezing up.

### Bypass line

The bypass line is a "detour line", which allows the compressed air system to continue operating even whilst maintenance of the dryer is in progress. However, during this time the air is not dried but flows through the bypass line past the dryer and through to the actual loads.

Filters in the bypass line are meaningful so that the actual loads are largely protected against dirt, water, and oil droplets even whilst maintenance is in progress.

## Signalling contacts of the control system

The control system is equipped with a digital input for the synchronised operation with a compressor. This feature allows for synchronised and thus efficient dryer operation with discontinuous compressor operation.

The control system can also be equipped with an optional operation signalling contact with which the dryer operation can be monitored from an external device. Dryers with the optional *dewpoint-sensing control* are equipped with such a contact as standard. It is used for the transmission of operating signals and for the output of dewpoint alarms.

## Compressor synchronisation

Compressor synchronisation helps reduce energy costs, as the dryer can be operated independently of the compressor.

When the compressor is switched off, the regeneration gas return ensures that regeneration is continued, as soon as a certain compressed air volume is reached behind the dryer. The regeneration process must be continued and ended so that the drying agent does not become unusable prematurely.

The compressor synchronisation controller is a higher-level controller than the pressure dew point controller (see below). When both options are in place, the compressor synchronisation controller is treated as the prime controller.

## Dewpoint-sensing control

With a dewpoint-sensing control system, you can operate the dryer in fixed or variable cycles. In the fixed cycle, switchover is effected after a fixed time period (usually after 5 minutes). In the variable cycle, the switchover is effected in relation to the dew point reached and the charging of the drying agent. The adsorption time in the variable cycle amounts to 60 minutes maximum.

## Pneumatic control

A pneumatic control system can be used wherever an alternative to the electronic control system is required, such as e.g. in explosion hazard areas.

## Paint compatible design

Paint shop plants impose particularly stringent requirements with regard to the cleanliness of the compressed air, as already the minutest contaminations can reduce the quality of the paint finish. Even minute quantities of oil and grease containing foreign materials or solvents — above all silicones — are sufficient to cause pits, discolorations, swellings, and other contaminations in the paint finish.

Dryers in a paint compatible design comprise seals and filters that are absolutely free of grease and silicon and thus ensure a high quality of the compressed air used for painting.

## Transportation, installation and storage



### **Danger due to incorrect transportation!**

**The dryer must be transported by authorized and qualified specialist personnel only. During transportation all applicable national regulations for accident prevention must be complied with. Otherwise there is a risk of personal injury.**

The manufacturer will not be liable for any damage caused by incorrect storage or incorrect transportation. Please note therefore the following instructions as well as the storage instructions on page 23.

## Information on transportation packaging

---

Depending on the type of transportation, the dryer is delivered in different types of packaging:

- All transportation types: the apertures of the dryer are closed off by means of plugs.
- In addition, when transportation is effected by air: the dryer is packaged in a wooden box.
- In addition, when transportation is effected by ship: the dryer is packaged in a film material and in a wooden box.

### If the packaging is undamaged

- ▶ The undamaged packaging should be removed only at the final installation site, as it offers protection against any weather influences.

## What to do in the case of transport damage occurring?

---

- ▶ Check whether only the packaging or the dryer itself were damaged.
- ▶ Inform the haulier immediately in writing of any damages.
- ▶ Contact the manufacturer urgently in order to report the damage. You will find the telephone number on page 6.



### **Warning!**


**A damaged dryer must not be taken into operation! Damaged components may lead to functional faults and possibly cause further damage.**

## Transporting and installing the dryer

### Requirements for the installation site

The conditions at the installation site have a large influence on the functional capability of the dryer and the service life of the drying agent. In order to ensure a mode of operation, which is as continuous as possible, and low maintenance, the installation site must meet the following requirements:

- The installation site must be located within a building. Protect the dryer against moisture. For outside installation (option) the instructions on page 18 must be complied with.
- The ambient temperature must not drop below +1 °C (33,8 °F). If necessary, an auxiliary heater is to be provided (for information on the auxiliary heater, see page 18).
- Heed the dryer's noise emission when selecting the installation location.
- The installation area must be level and firm. It must have the necessary carrying capacity for the weight of the dryer. The weight of the dryer is specified in the technical data section of the annex.
- The dryer should be installed with sufficient spacing at the top, sides, and rear, in order to be able to carry out maintenance work and change the drying agent without any hindrances (see figure).



*Necessary spacing at the top and sides = min. 1 m*

If in doubt, the installation site must be inspected by specialists. If you have any queries in this regard, please contact the manufacturer (for details see page 6).

### Transporting and installing the dryer

#### Transportation using lifting or forklift truck




#### **Warning against damage to property!**

**Dependent on its size, the dryer is delivered in a cardboard box or in horizontal position on a transport pallet. Top and sides have not been designed for mechanical loads.**


**Do not place any load onto the top face. Do not stack.**

**Therefore, always transport the dryer on a lifting or forklift truck.**

- ▶ Secure the cardboard box or pallet on the lifting or forklift truck against sliding movements.
- ▶ Transport the dryer to its installation site.
- ▶ Remove the packaging of the dryer.



K-MT 1-4: Dryer in a cardboard box



K-MT 6-8: Dryer on transportation pallet



**Note the weight of the dryer!**


Depending on its size, the dryer may weigh up to approx. 80 kg. Take this into account with regard to the following work steps!

- ▶ Carefully place the dryer in an upright position.
- ▶ Place the dryer at its installation site.

**Anchor dryer to the floor**

The upright stand profiles of the dryer are provided with pre-drilled anchorage bores (see figure).

- ▶ Use suitable attachment material to anchor the dryer to the floor.
- ▶ *In the case of vibrating floors:* place the dryer on suitable vibration dampers.



Bores on the stand profiles

**Mount dryer on the wall**

The stand profiles can be rotated by 90° towards the rear side of the dryer and secured in this position (see arrow in above figure).

- ▶ Remove the screws at the muffler and the stand profiles. Rotate the stand profiles by 90° until the auxiliary holes for the securing screws and the muffler are aligned with each other. Retighten the screws securing the stand profile and the muffler.
- ▶ Use suitable attachment material of sufficient carrying force to anchor the dryer to the wall.

---

## Storing the dryer

---

If the dryer is to be stored for an extended period of time, the storage location must meet the following conditions:

- The dryer must not be stored in the open air.
- The storage room must be dry.
- The storage room must be free from dust or the dryer must be covered by a protective sheet.
- The storage room must have an ambient temperature of at least +1 °C (33,8 °F).

In order to store the dryer proceed as follows:

- ▶ Take dryer out of operation as described on page 37.
- ▶ Ensure that the compressed air inlet valve installed by the owner, and the installed compressed air outlet valve installed by the owner, are both closed, and that the dryer is depressurised.
- ▶ Disconnect dryer from the compressed air system.
- ▶ Disconnect the dryer from the electrical power supply and all external lines.
- ▶ Use film material or similar to close the compressed air inlet apertures and compressed air outlet apertures on the dryer in order to protect them against contamination.
- ▶ If possible cover dryer with a protective sheet.

The dryer can now be stored for long periods.

**Note:**

**If you wish to take the dryer back into service after an extended period of storage, please proceed as described for its first commissioning and start-up (see page 32).**

### Store drying agents

- ▶ Do not store drying agents in the open air.
- ▶ Protect drying agents against humidity.

## Installation



**Only authorized and qualified specialist personnel may carry out work on pipes and electrical systems.**

As soon as the dryer has been set up at its installation location, you can install the compressed air infeed and outlet lines and make the electrical connections.

## Preconditions for installation

For a correct installation the following preconditions must be met on the part of the owner.

- Connections and lines for the infeed and outfeed of compressed air must be provided.
- A compressed air inlet valve as well as a compressed air outlet valve must be installed by the owner, so that the dryer can be installed and maintained in a depressurised condition (see also the installation example on page 25).
- All pipes, couplings, and connections must have the correct diameter and match the operating pressure.



**Hazard caused by exceeding the limit values!**

**A safety device must be provided in order to protect against the maximum permissible operating pressure from being exceeded.**

**The safety device must be installed so that the dryer is reliably protected from exceeding the maximum permitted operating pressure even when the temperature of the compressed gas increases.**

The data required to meet these preconditions are contained in the technical documentation attached in the annex.



**Warning!**

**If the above preconditions are not complied with, a safe operation of the dryer cannot be assured. Also, the functionality of the dryer may be detrimentally affected.**

## Connect piping

In order to ensure that the dryer operates optimally, the dryer must be assembled into the compressed air system free of all stresses.

- ▶ Ensure before connection that all infeed and outfeed compressed air lines and valves are clean and undamaged.
- ▶ Check the bolt connections and retighten if necessary, as they could have worked loose during transportation.
- ▶ Remove plugs on the pressure inlet and outlet.




**All piping must be free from any stress and tension whatever!**

**Pipes subject to stress may burst due to the load placed on them during operation. This may cause damage to property and personal injury.**

- Use steel pipes to connect the dryer to the compressed air system.

The following figure shows an installation example.



*Example of an installation with bypass line*

- The connection lines for the upstream filter (3) are to be installed at a slight incline in the direction of the upstream filter.
- One shutdown valve each (2, 6) is to be installed at the compressed air inlet and outlet ends of the dryer.
- *If you fit a bypass line (8) with additional shutdown valve:*  
Fit the line such that, when carrying out maintenance work on the dryer, the line system can continue to be supplied with compressed air.

## Installing the electrical connection



**Warning against electrical voltage**


**Only qualified specialist personnel may carry out work on the electrical system!**

## Installing the supply cable

The components of the dryer have been connected to the control cabinet at the factory. You only need to connect the control cabinet to the electrical supply cable.

The switchbox is provided with a connector where electrical power must be connected.

- ▶ Ensure that the cross-section of the electrical supply cable corresponds to the power rating of the dryer and the electrical voltage provided by the customer.
- ▶ Make the electrical supply cable to the dryer voltage-free.
- ▶ Secure the electrical supply cable to the dryer against switch-on.
- ▶ Undo bolt (1) on the connector and withdraw connector with seal from the switchbox.
- ▶ Use a suitable tool to remove the terminal block from the connection box.
- ▶ Undo the PG union and pull the cable through the aperture (3). The exposed phase ends should not be longer than 35 mm max.



Connect electrical cable to device adapter

- ▶ Now make the cable connection as follows:
  - Earth to terminal PE
  - L1 to terminal 1
  - N to terminal 2

Terminal 3 is not used.

- ▶ Fit terminal block into the connector and use bolt to remount the connector with seal on the switchbox.
- ▶ In all phases the dryer must be protected against short circuits by means of fuses.
- ▶ In order to relief cable strain, re-tighten the PG union.


## Connecting the external signalling lines

### For compressor synchronisation

The controller is fitted as standard with a digital input which makes the dryer regeneration dependent on operation of the compressor (switch S1 on the controller's circuit board, see also figure below).

If switch S1 is in the ON position, operation of the compressor and dryer regeneration run synchronously: When the compressor is stopped, the dryer regeneration also stops. When the compressor is restarted, regeneration also restarts.

If switch S1 is in the OFF position, any regeneration process which has been started, is always continued until completed.



To install the external line, proceed as follows:

- ▶ Connect the signalling line to the potential-free busbar connection of the compressor to terminals 1 and 2 on the control board (see circuit diagram).

#### For operation monitoring system (optional)

Operators have the option to connect the dryer to a fault signalling system, connecting the respective line to a potential-free operation signalling contact. With this option, the following statuses and events can for example be transmitted to a remote control room:

- Dryer on (contact made)
- Power supply disconnected (no contact)
- Dewpoint alarm (only with *dewpoint-sensing control* option, no contact)

To install the external lines, proceed as follows:

- ▶ Connect the lines of the fault signalling system to relay K5 (see circuit diagram).

## Check bolt connections


Before the initial start-up:

- ▶ Check all unions and bolt connections as well as the terminals in the control cabinet for secure seating; re-tighten if necessary.

## Mount mufflers to K-MT 3-4

The mufflers of dryer K-MT 3-4 are enclosed as separate items. They must be mounted before commissioning the dryer.

- ▶ Take mufflers out of the packing.
- ▶ Screw the reducer (1) into the opening at the solenoid valve block.
- ▶ Insert muffler (2) into the reducer and screw on tightly.



Mount muffler

## Start-up

- Carry out all prescribed tests and checks.
- Before start-up, ensure that no tools or other foreign parts have been left lying in a part of the dryer where they might pose a hazard to the dryer being started up.

## Requirements for initial start-up

---

For the first start-up the following preconditions must have been met:

- The pipe system is free from
  - scales
  - thread abrasions
  - welding beads and
  - other contaminations.
- All shutdown valves
  - of the compressed air inlet and outlet valves installed by the owner
  - in the bypass line (if available)are closed.
- The dryer is correctly sited and installed.

## Checks before start-up

Ensure that

- all pipe, cable and bolt connections on the dryer have been retightened,
- no pipes chafe against body edges,
- all mountings are perfectly secure,
- the electrical connections are in safe contact and in good condition,
- owner-end and pressurised parts such as safety valves or other devices are not blocked up by dirt or paint,
- all compressed air system parts which are pressurised (valves, hoses etc.) are free from wear symptoms and defects.

## Setting times of the operating phases

In its standard version the dryer is delivered with a time-dependent control system. The phase sequence occurs in a fixed cycle.

With the optional dewpoint-sensing control, the dryer can also be operated at variable cycles (depending on the dewpoint).

The following table provides information on the duration of the individual phases.

Phase duration	Fixed cycle	Variable cycle
Adsorption	5 min	60 min, maximum
Regeneration, total	5 min	5 min
– of which: expansion time	~ 0.2 min	~ 0.2 min
– of which: dehumidification time	~ 4 min	~ 4 min
– of which: pressure build-up	~ 1 min	~ 1 min
Standby	—	~ 55 min, maximum


## Overview of operating and control elements

### ON/OFF switch

The ON/OFF switch (2) is located to the side of the switchbox and above the mains plug (1, see figure):

- If it is set to **0**, the power supply is disconnected and the dryer is switched off. The main valves (V1, V2) are open, while the expansion valves (V3, V4) are closed. This means that the air can circulate in the main processing direction, even if the dryer is switched off.
- If the switch is set to **I**, the dryer is switched on and begins to operate in fixed cycle mode (i.e. time-controlled).
- If the switch is set to position **II**, the dryer is switched on and begins to operate
  - with compressor synchronisation
  - in variable cycle mode (i.e. dewpoint-controlled).


Position **II** is only relevant for operation with the optional *compressor synchronisation* and/or *dewpoint-sensing control*.



Switchbox with ON/OFF switch

## Display panel

The display panel at the switchbox is equipped with LEDs (light emitting diodes) and a digital display, indicating the operating status of the dryer:




Display panel at the switchbox

### LED Power (1)

LED is on when dryer is switched on.

### Flow diagram (2)

The current operating phases of the dryer are indicated by means of 4 LEDs:



Depending on the operating phase, the following LEDs might be on simultaneously:

*Adsorption B1 and regeneration B2* or  
*regeneration B1 and adsorption B2.*

### Digital display (3)

The digital display shows the individual programme steps and the respective remaining time. For details regarding the sequence of the individual processing steps and their duration, please refer to the logic control diagram, page 62.

Display		Explanation
2	215	Default display: The figure to the left indicates the current processing step; the figure to the right shows the remaining time in seconds.  In this example, step 2 is being completed, whereby there are 215 seconds remaining.
SEr.		After 8000 operating hours, "SEr." (service) is displayed for periods of 1 minute, alternating with the default display.  Notify the service personnel of the manufacturer, as a routine service is now due.
- 25		With the <i>dewpoint-sensing control</i> option, the display shows the currently measured dewpoint instead of the default data. The range of display is -100 °C (-148 °F) to +20 °C (68 °F).  If the measured dewpoint exceeds the preset alarm limit (5 °C (41 °F) above the switchover value), the displayed dewpoint value is flashing.

With the optional *dewpoint-sensing control*, the following error messages might be displayed:

Display	Cause
+20	■ Upper measuring range limit exceeded
999	■ Dewpoint sensor defective
sens or -999	■ Dewpoint sensor not powered ■ Cable defective or disconnected ■ Sensor defective

### LED Economy cycle (4)

This LED is only relevant in units that are equipped with the optional *dewpoint-sensing control*. The diode lights up when the dryer is switched on and in the standby phase and no regeneration air is required.

### Differential pressure gauge (only K-MT 6-8)

On each of the upstream and downstream filters, a differential pressure gauge is installed. The differential pressure between the filter inlet and outlet ends is used as an indicator for the degree of filter element contamination. The indication should be within the green range up to 0.35 bar maximum, otherwise read the instructions on page 44.

## Emergency shutdown

In the event of an emergency, shut down the dryer as described on page 37.

## Start up dryer



### Warning against sudden air ejection!

During expansion the pressure is released suddenly through the muffler:

- A loud cracking noise occurs which can injure your hearing.
- Particles carried in the air flow act like bullets and can injure your eyes or skin.

**Always wear eye and ear protection, therefore, when you are in the vicinity of the dryer!**



### Hazard due to a sudden release of pressure!

**Never remove any parts of the dryer, or manipulate the same in any way, for as long as the plant is still pressurised! A sudden escape of pressure may cause serious injuries.**

**Before carrying out any work on the dryer, first depressurise the plant.**

- The more powerful the dryer is, the more noise may be generated during operation. Therefore, the operator must provide suitable protective equipment (e. g. ear protection).
- Only operate the dryer within the permissible limits. By operating the dryer in conditions for which it has not been designed, functional faults may be caused.
- Depending on the size of the dryer and the compressed air network and the respective legal requirements in your country, it may be necessary to perform initialisation according to the directive for pressure equipment 97/23/EC.
- Check the dryer regularly for externally visible damage and defects. Any changes, even in its operating behaviour, must be reported immediately to the competent office or person.
- In the event of an emergency or if a safety-relevant disruption occurs (e.g. escaping compressed air, defective component), immediately close the compressed air supply line and set the ON/OFF switch of the dryer to 0 in order to disconnect it from the power supply. Afterwards depressurise the dryer (see also chapter , page 37). The unit may only be restarted after all defects have been eliminated.

## Open compressed air supply and switch on dryer

For start-up, please proceed in the sequence shown here.

- ▶ Ensure that the compressed air inlet and outlet valves installed by the owner are closed (see installation example on page 25).
- ▶ Ensure that the compressed air system upstream of the dryer is pressurised. If necessary, pressurise (switch on compressor).



### Slowly open compressed air inlet valve!

**Avoid sudden pressure build-up in any circumstance! If pressure builds up too fast, this may cause damage to the dryer. Therefore, the compressed air inlet valve must always be opened quite slowly!**

- ▶ Slowly open the compressed air inlet valve, installed by the owner, upstream of the dryer.
- ▶ Switch on dryer: to this end, set the ON/OFF switch to I.



ON/OFF switch

If the dryer is taken into operation for the first time, or after a change of drying agent, the following intermediate step is meaningful. In the case of a restart situation, the following intermediate step can be skipped.

Operating the dryer for the first time (or after a change of drying agent) separately

Depending on the transportation and storage conditions, the drying agent in the chambers can already be loaded with humidity from the environment. At each first start-up it makes sense therefore to operate the dryer from some time separately from the compressed air system. This causes the drying agent in each chamber to be regenerated repeatedly and thus to be prepared optimally for the take-up of humidity.

#### Note:

**Depending on the pressure dew point to be achieved, we recommend to operate the dryer at first start-up without compressed air consumption:**

- for at least 4 hours at a pressure dew point of  $-25$  to  $-40$  °C or
- for approx. 3 to 5 days at a pressure dew point of  $-70$  °C.

If you wish to take the dryer into operation in accordance with our recommendation, proceed as follows:

- ▶ Ensure that the compressed air outlet valve installed by the owner is closed.
- ▶ Keep the compressed air outlet valve closed for the time period recommended above.

Then the dryer can be taken into service in the compressed air system as described in the following section:

**Operate dryer immediately in the compressed air system**

- ▶ Ensure that the compressed air system downstream of the dryer is pressurised or that a start-up device (option, see page 18) was installed into the compressed air system directly downstream of the dryer. The importance of this increases with the size of the compressed air system downstream of the dryer. Smaller compressed air systems can be pressurised also by means of compressed air fed through the dryer.



### **Slowly open compressed air outlet valve!**

**Avoid a sudden drop in pressure in any circumstance! If pressure drops too fast, this may cause damage to the dryer. Therefore, the compressed air outlet valve must always be opened quite slowly!**

- ▶ Slowly open the compressed air outlet valve installed by the owner. The pressure should not drop below the operating pressure (if poss.). If necessary, keep the compressed air outlet valve in a slightly open position until the compressed air system downstream of the dryer has filled up completely; only then should the valve be opened fully.

The dryer has then be taken into operation within the compressed air system.

### **In the event of a fault**

In the event of an emergency or if a safety-relevant disruption occurs (e.g. escaping compressed air, defective component), immediately close the compressed air supply line and set the ON/OFF switch of the dryer to 0 in order to disconnect it from the power supply. Afterwards depressurise the dryer (see also chapter , page 37).

Then proceed as follows:

#### **Remedy fault**

- ▶ Look up possible cause of the fault, and how to remedy the same, in the table on page 54.
- ▶ Remedy fault.
- ▶ Repeat the start-up procedure.

## **Changing cycle mode (optional)**

---

### **When *can* I change cycle mode?**

If the dryer has been successfully commissioned and is equipped with one of the following options:

- *compressor synchronisation* or
- *dewpoint-sensing control*

it can be set to *economy cycle* mode.

### **When *should* I change cycle mode?**

Cycle changes should be made during the pressure build-up phase and prior to switchover; during this phase, the pressure in both chambers is just below operating pressure so that a fast pressure build-up is prevented when the chambers are switched.

During this period, only the adsorption LED is on in the diagram, and the digital display shows step 4 or step 9 for the duration of 1 minute (see logic control diagram; not displayed with dewpoint sensing).

## Which cycle modes can I choose?

If the dryer is connected to a *compressor synchronisation system* and is equipped with the *dewpoint-sensing control* option, these two optional devices can only be started together. The compressor synchronisation has thereby precedence over the dewpoint-sensing control.

### With compressor synchronisation (optional)

If compressor synchronisation is enabled, the dryer can only be operated in conjunction with the compressor. As soon as the compressor is switched off, the dryer is automatically set to standby mode.

In standby mode, the control system remains on, and the dryer is ready for the next switchover, which is made as soon as the compressor is switched on.

### With dewpoint-sensing control (optional)

Dryers equipped with dewpoint-sensing control operated in variable cycle mode, based on the measured dewpoint of the dried air at the compressed air outlet. As soon as a certain dewpoint is reached, as the drying agent in the absorbing chamber is saturated, the chambers are switched.

The dewpoint at which a switchover is made is preset at the factory.

## How do I change cycle mode?

- ▶ Wait until the dryer has reached the pressure build-up phase (phase prior to switchover).  
One LED for *Adsorption B1/B2* is on in the flow diagram.
- ▶ Set the ON/OFF switch to position **II**.



ON/OFF switch

The programme continues the cycle.

## Monitoring dryer operation

The dryer operates fully automatically. However, you should carry out the regular checks described in the Chapter *Maintenance and repair of the dryer*.



### Warning against sudden air ejection!

**During expansion the pressure is released suddenly through the muffler:**

- **A loud expansion noise is caused which may damage your hearing.**
- **Particles carried in the air flow act like bullets and can injure your eyes or skin.**

**Always wear eye and ear protection, therefore, when you are in the vicinity of the dryer!**

## With dewpoint-sensing control (optional)

### Display of dewpoint

If the dryer is equipped with a dewpoint-sensing control system, the digital display at the front of the switchbox shows the currently measured dewpoint. The range of display is  $-100\text{ °C}$  ( $-148\text{ °F}$ ) to  $+20\text{ °C}$  ( $68\text{ °F}$ ).

If the set dewpoint is exceeded, the system automatically completes a switchover between the chambers. The dewpoint at which a switchover is made is preset at the factory.

- ▶ After commissioning or extensive maintenance work, check the dewpoint display at the dryer.

Under certain circumstances, the desired dewpoint is only reached after prolonged operation.

### Error messages

If the measured dewpoint exceeds the preset alarm limit ( $5\text{ °C}$  ( $41\text{ °F}$ ) above the switchover value), the displayed dewpoint value is flashing. In addition, an error message can be issued through the potential-free busbar.

Error codes and their causes:

Display	Cause
<b>+20</b>	■ Upper measuring range limit exceeded
<b>999</b>	■ Dewpoint sensor defective
<b>sens</b> or <b>-999</b>	■ Dewpoint sensor not powered ■ Cable defective ■ Sensor defective

For instructions on how to eliminate faults, see chapter *Identify and eliminate faults*.

# Shutdown and restart dryer

In the following cases, the dryer must be fully shut down and depressurised:

- In the event of an emergency or malfunction
- For maintenance work
- For dismantling



## Risk of injury from escaping compressed air!

**Never remove any parts of the dryer, or manipulate the same in any way, as long as the unit is pressurised! Suddenly escaping compressed air might cause serious injuries.**

**Prior to any work, release all pressure from the unit.**



## Caution!

**Risk of damage to the dryer, if it is switched off during the expansion or drying phase.**

**During these phases, the pressure in the regenerating chamber is released to ambient pressure: If the main valve is opened, as the dryer is switched off, there is a sudden pressure build-up in the chamber. This might result in**

- damage to the drying agent, and
- excessive abrasion, with negative impact on the regeneration capacity.

**Before switching off the dryer, wait until it has reached the pressure build-up phase or is in standby mode (before switchover).**

### Note:

**If the unit is equipped with a compressor synchronisation system, first switch off the compressor and then wait until the dryer has reached the standby phase before switching it off with the ON/OFF switch.**

**This ensures that the regeneration cycle is completed, and that the pressure in both chambers is at the same level.**

### Note:

**As soon as the dryer is switched on again, the programme continues the cycle from the point at which it has been stopped.**

## Emergency shutdown

In any emergency proceed as described in the next section.

## Depressurising and shutting down the dryer

---

### Close compressed air feed line

- ▶ Close the compressed air inlet valve (provided by the operator).

### Disconnect voltage supply

- ▶ Switch off the dryer by setting the ON/OFF switch to position 0.



ON/OFF switch

### Disconnect dryer from compressed air system

- ▶ Close the compressed air outlet valve installed by the owner.
- ▶ If available, open bypass line.

### Depressurise dryer

- ▶ Depressurise dryer, e.g. by opening the manual drain at the downstream filter.

## If work is to be carried out on the electrical system

---

- ▶ Depressurise and shut down the dryer, following the instructions in the above chapter.



### **Risk of injury due to voltage-carrying parts!**

**The electrical supply cable and external power lines are live even after the dryer is switched off and, in the event of body contact, may cause serious injury! Before carrying out any work on the electrical system, the electrical supply cable and all external power lines must be made voltage-free!**

- ▶ Make the electrical supply cable to the dryer voltage-free.
- ▶ Secure the electrical supply cable to the dryer against switch-on.

## Restart

---

Depending on the fittings installed by the operator and the actual pressure conditions, the unit might have to be restarted at operating pressure. The following general rules apply:

- When switched off, the dryer is open in main flow direction. With the optional *start-up device*, the set minimum pressure must however be reached prior to restart.
- A return flow is only possible in connection with the optional *regeneration gas return* (and provided that the pressure outlet valve is open).

- If the dryer is equipped with a dewpoint-sensing control system, it is depressurised gradually, according to the read measuring current.

### If compressed air system and dryer have remained at operating pressure

- ▶ Ensure that the compressed air inlet valve (provided by the operator) is open.
- ▶ Set ON/OFF switch to **I**. The programme continues the cycle from the point at which it was interrupted.



ON/OFF switch



#### Slowly open compressed air outlet valve!

**Avoid a sudden drop in pressure in any circumstance! If pressure drops too fast, this may cause damage to the dryer. Therefore, the compressed air outlet valve must always be opened quite slowly!**

- ▶ Slowly open the compressed air outlet valve installed by the owner. The pressure should not drop below the operating pressure (if poss.). If necessary, keep the compressed air outlet valve in a slightly open position until the compressed air system downstream of the dryer has filled up completely; only then should the valve be opened fully.
- ▶ If available, block off bypass line.

The dryer is now in operation again and operates fully automatically.

### If compressed air system and dryer have not remained at operating pressure

- ▶ If disconnected, reconnect the voltage supply of the dryer.
- ▶ Ensure that the manual drain on the downstream filter is closed.
- ▶ Pressurise and switch on the dryer as described in the section *Open compressed air supply and switch on dryer* on page 32.

The dryer is now in operation again and operates fully automatically.

# Maintenance and repair of the dryer

In order to allow maintenance work on the dryer to be carried out efficiently and without danger for maintenance personnel, you should comply with the following instructions.

## Notes on maintenance



### Warning!

**Maintenance tasks may be carried out only by authorized and qualified specialist personnel, and only with the plant in a switched off and depressurised condition.**

### Note:

**In order to ensure perfect maintenance and reliable operation we recommend that you conclude a maintenance contract (For telephone number, see page 6).**

- Carry out all maintenance work only when the plant has been shut down and depressurised!
- Bolt connections must be undone with care! Note ram pressure values! Otherwise emerging media may cause personal injury.
- Do not modify the factory settings of the control system in any way without prior consultation with the manufacturer.
- Never carry out any manipulations on a hollow profile vessel or modify the same in any way!
- Following maintenance work, always check all flange and bolt connections for leakage and secure seating.
- Never use pipes and fittings as steps or holding points! The components might fracture, or the distortions which occur may cause internal damage on the dryer. There is a risk of injury by slipping off the components, components breaking off, and expanding compressed air!
- Never leave tools, loose parts or cloths at or on the dryer.
- Only use replacement parts that are suitable for the relevant function and meet the technical requirements stipulated by the manufacturer. This is always the case, if you use original replacement parts only.

## Regular maintenance intervals

### Note:

If a chamber has been depressurised, e.g. after completion of the expansion phase, and the pressure remains above 0 bar, the chamber is pressurised by what is known as ram pressure. This might be due to

- blockage at the muffler(s)
- contamination of the perforated plates
- spent drying agent

To prevent such malfunctions, regularly service the dryer as described below.

The table provides an overview of the maintenance work to be carried out. The individual tasks are described in the following pages.

Component	Maintenance task to be carried	Maintenance interval						
		daily	weekly	monthly	12 months	24 months	48 months	see page
Complete dryer	Carry out visual and function checks.	▲						42
Upstream and downstream filter	Check pressure difference at the upstream and downstream filters (only K-MT 6-8). If the pressure difference is greater than 0.35 bar, replace the respective filter element.		▲					43
	Replace all filter elements after 1 year of operation.				●			44
Upstream filter	Check function of the condensate trap, clean if necessary.			▲	●			43
Muffler	Clean muffler or renew filter element.				●			44
Sensor of optional dewpoint-sensing control system	Must be calibrated.				●			46
Solenoid and check valves	Check function; replace if necessary.				▲	●		47
Seals, perforated plates, drying agent	Replace.						●	49

Codes:           ▲ check           ● replace

## Instructions for use of the dongle

If the message **SEr.** is displayed on the display of the Multitronic controller, the dryer is due for servicing. The message appears, flashing every 60 seconds, once the preset number of operating hours (e. g. 8000 oh) has been reached. After maintenance has been carried out, you can use the dongle to reset the counter to 0 and delete the message from the display. A dongle is enclosed with every service kit. You can also order dongles individually from the manufacturer. Each dongle can only be used once.

- ▶ Switch off the controller. Caution! The electric line is still live. Do not touch live parts!
- ▶ Open the lid to the Multitronic controller. The circuit board is housed underneath it.
- ▶ Slot the dongle into the dongle interface *X9 PC*.
- ▶ Press and hold the reset key *S3*.
- ▶ Switch on the controller. The following appears in the display:

for a short time then flashing	<b>0.SET</b> <b>OFF</b>
-----------------------------------	----------------------------

The service counter is then reset to 0.

If the following appears in the display:

for a short time then flashing	<b>FAIL</b> <b>OFF</b>
-----------------------------------	---------------------------

this means that the dongle has already been used once and cannot be used again.

- ▶ Switch off the controller again and remove the dongle.
- ▶ Dispose of the unusable dongle and use a new one.

## Daily maintenance tasks

### Carry out visual and function check on the complete dryer

- ▶ Check dryer for external damage or unusual noise generation.
- ▶ Duly eliminate any defects found.

If message **SEr.** is displayed, a routine service must be completed:

- ▶ Contact the service department of the manufacturer.

### Clean dryer

- ▶ Remove any loose dust by means of a dry cloth, and, if required, also by means of a moist and well wrung cloth.
- ▶ Clean the surfaces with a moist well wrung cloth.

## Weekly maintenance tasks

### Check differential pressure on the filters (only in K-MT 6-8)

- ▶ Check the differential pressure on the pressure gauge of the filter.

The differential pressure should be 0.35 bar max. If the differential pressure exceeds 0.35 bar, we recommend that you replace the filter element (see page 44). The filter elements must be replaced in any case every year.

## Monthly maintenance tasks

### Check the function of the condensate trap on the upstream filter

A level-controlled condensate trap is installed at the upstream filter. The condensate trap drains the condensate automatically whenever a predefined fill level is reached. This trap prevents that the humidity separated from the filter ingresses into the dryer and has a detrimental effect on the drying agent.

Check the condensate trap as follows:


- ▶ If a permanent flow noise can be heard when the discharge valve is closed, this indicates a leakage. The condensate trap is poss. contaminated or defective.
- ▶ Turn knurled screw (see fig., item 1) on the housing bottom to the right. The condensate trap opens.

If the condensate trap

- operates correctly, some condensate or even just compressed air will emerge.
- is defective, an unusual amount of condensate emerges, or neither condensate nor compressed air emerge.

If no compressed air or an unusually large amount of condensate, or no water condensate at all, emerge, you have to remove the condensate trap, clean and if necessary, replace the same. To this end, proceed as follows:

- ▶ Depressurise the dryer and shut it down (see page 37).
- ▶ Unscrew the bottom section of the filter housing; remove the condensate trap, clean or fit new condensate trap.
- ▶ Refit bottom section of the filter housing: first screw on very tightly then unscrew by a quarter turn.
- ▶ Restart dryer (see page 39).
- ▶ Recheck function of the condensate trap.




## Maintenance work to be completed every 12 months

### Renew filter elements on the filters

The filter elements must be replaced every 12 months.

- ▶ Depressurise dryer and take out of service (see page 37).
- ▶ Remove the bottom section of the filter housing (see figure).
- ▶ Replace filter element.
- ▶ Refit bottom section of the filter housing: first screw on very tightly, and then unscrew by a quarter turn.
- ▶ Dispose of used filter element in accordance with the applicable regulations.
- ▶ Restart dryer (see page 39). Check the all filters for leaks.



Open filter

### Check mufflers

The dryer is either equipped with a standard muffler or a fine filter muffler. If the respective muffler becomes blocked, a dam pressure is generated which in extreme cases may cause the muffler to burst.



#### **Hazard caused by blocked muffler!**

**Blocked mufflers can cause a dangerous overpressure to build up which may cause the mufflers to burst. Flying fragments may cause personal injury and damage to property.**

**Therefore, mufflers must be checked at least once a year and cleaned or renewed if they are contaminated.**



#### **Warning against sudden air ejection!**

**During expansion the pressure is released suddenly through the muffler:**


- **A loud cracking noise occurs which can injure your hearing.**
- **Particles carried in the air flow act like bullets and can injure your eyes or skin.**

**Always wear eye and ear protection, therefore, when you are in the vicinity of the dryer!**


The correct procedures for all muffler versions are described below.

### Clean or renew standard mufflers

- ▶ Depressurise the dryer and shut it down (see page 37).
- ▶ Unscrew muffler as shown in the opposite figures:
  - K-MT 1-2 = Pos. A,
  - K-MT 3-4 = Pos. B
  - K-MT 6-8 = Pos. C




- ▶ Check for contamination:
  - Blow out with compressed air for cleaning
  - or renew muffler, if necessary.
- ▶ Screw on the muffler using a wrench on the hexagon muffler collar.
- ▶ Restart dryer (see page 39).



*Undo muffler*

### Replace the element in the fine filter muffler

- ▶ Depressurise the dryer and shut it down (see page 37).
- ▶ Undo knurled screw on the lid cap and remove cap.
- ▶ Unscrew old filter element. Arrows on the element bottom mark the direction of rotation.




*Renew muffler element*

- ▶ Insert new filter element and screw on tightly.
- ▶ Re-engage lid cap at the top section of the housing and fix in position by means of the knurled screw.
- ▶ Restart dryer (see page 39).

## Recalibration of dewpoint sensor (optional)

In order to ensure accurate dewpoint measuring, we recommend recalibrating the dewpoint sensor at least every 12 months. The recalibration must be carried out by the manufacturer. This period depends however on the actual application and might thus be extended accordingly.



Dewpoint sensor (1)




### Warning!

**The dew point sensor is a sensitive measuring device. It can be damaged if subjected to forceful vibrations or shocks. Therefore, please handle the dew point sensor with great care at all times.**

For calibration, the pressure dewpoint sensor must be dismantled. In order to limit the impact on the dryer operation to a minimum, we recommend that you contact the manufacturer well in advance (for contact details, see page 6) and order a new dewpoint sensor. Upon receipt of your old pressure dewpoint sensor, we will issue a credit note.

After receipt of the new pressure dewpoint sensor, replace the sensor as follows:

- ▶ Hold the box of the dewpoint sensor ready.
- ▶ Release pressure from dryer and shut down the unit (see page 37).



Installing / dismantling pressure dewpoint sensor

- ▶ Loosen the screw at the adapter (1) and disconnect signal cable with the adapter and seal.
- ▶ Remove dewpoint sensor from the sensor cell (3) by turning the nut (2).
- ▶ Take the new dewpoint sensor (2) from the box, remove the protective caps (4, 5) and screw it into the sensor chamber (3).
- ▶ Place seal onto sealing face; connect adapter (1) and secure it by tightening the screw.

- ▶ If no other maintenance work is to be carried out: Restart the dryer (see page 39).

**Note:**

**For posting, the dewpoint sensor must be equipped with protective caps and placed in a solid box.**

- ▶ Place the protective caps (4, 5) onto the old dewpoint sensor and pack it properly in the box.
- ▶ Send the old dewpoint sensor to the manufacturer.

## Check solenoid and check valves


Proceed as described in the next chapter for maintenance work to be completed every 24 months.

## Maintenance work to be completed every 24 months

### Replace check valves

Check valves are wear parts and must thus be replaced every 24 months, even if no damage is visible.

- ▶ Release pressure from dryer and shut down the unit (see page 37).
- ▶ Remove the securing screws at the rear of the check valve plate.
- ▶ Insert new balls and new springs and ensure that they are not jammed.
- ▶ Replace the seals at the securing screws and tighten the screws.
- ▶ With regeneration gas return (optional):  
Also replace the two additional check valves, following the above instructions.
- ▶ If no other maintenance work is to be carried out: Restart the dryer (see page 39).



*Check valves*


### Replace solenoid valves

Solenoid valves are wear parts and must thus be replaced every 24 months, even if no damage is visible.

- ▶ Release pressure from dryer and shut down the unit (see page 37).

Preparation for the replacement of all four solenoid valves:

- ▶ Check the specifications of the valves:
  - The rated voltage of the solenoids (1) must correspond to that indicated on the type plate of the dryer.
  - The solenoid valves Y1/Y2 (at the rear of the dryer) must be normally open (check details on the spring bracket (2)).
  - The solenoid valves Y3/Y4 (at the front of the dryer) must be normally closed (check details on the spring bracket (2)).
- ▶ Position the new solenoid valves at the points at which they are to be mounted in order to prevent any confusion at a later stage.



Solenoid valve

For each solenoid valve, proceed as follows:

- ▶ Remove solenoid valve from the holder (3). Remove the valve together with the solenoid and the diaphragm (4).
- ▶ Insert new diaphragm with guide (4) and secure it to the holder (3).
- ▶ Position new solenoid (1) onto the armature and secure it to the spring bracket (2).
- ▶ If no other maintenance work is to be carried out: Restart the dryer (see page 39).

## Maintenance work to be completed every 48 months

To complete the following maintenance tasks, you must dismantle the plates and the vessels. We therefore recommend that you carry out these tasks together.

### Replace perforated plates, seal and drying agent

#### Replace upper perforated plates and seal

Perforated plates are fitted under the check valve plate and over the solenoid valve plate; these retain the drying agent. If these perforated plates become blocked, a dam pressure is generated which can cause compressed air fluctuations in the compressed air system.

In order to remove the upper perforated plates, the check valve plate must be removed.




#### Risk of falls!

**The dryer must not be misused as a climbing aid! The components have not been designed for such loads and could fracture.**

**Only use approved climbing aids when disassembling the check valve plate.**

- ▶ Depressurise the dryer and shut it down (see page 37).
- ▶ Loosen the screws at the check valve plate and lift off the plate.
- ▶ Removing and replacing seals, perforated plates, pressure springs and demisters.



*Removing the check valve plate*

Before reassembling the check valve plate, you should replace the drying agent.

## Replace drying agent

The service life of the drying agent is usually approx. 3 to 5 years. However, in favourable installation conditions, the change of drying agent may be carried out at a substantially later date (for notes on the installation site, see also page 21). The change interval is determined by the degree of contamination of the compressed air (which can be minimised by regularly replacing upstream filter elements). Oil, dust, and dirt particles cover the drying agent surface and reduce its effective surface, in part quite irreversibly.

If in doubt, have a sample of your drying agent assessed by specialists. Send a sample of approx. 200 g to the manufacturer (for address, see page 6).

Comply with the following safety notes when changing the drying agent:



**Wear eye protection and dust mask due to increased dust generation!**

**When emptying the drying agent, increased dust generation may occur.**

**In order to avoid any eye irritations, wear protective goggles!**



**In order to avoid any dust inhalation, wear dust mask!**



**Risk of skidding!**

**If drying agent has been spilt on the floor, there is a risk of skidding caused by the drying agent beads. Therefore, spilt drying agent must always be taken up immediately.**

## Remove used drying agent

- ▶ Use an industrial vacuum cleaner to Hoover up carefully the drying agent out of the chambers.



**Warning!**


**If the dryer is not used within specifications, the drying agent can be contaminated with pollutants. Always take this into account for the environmentally safe disposal of the drying agent. The waste code numbers of the drying agent can be obtained from the manufacturer (see page 6).**

- ▶ Dispose of the used drying agent in accordance with all applicable regulations.

Before filling in new drying agent, we recommend that you replace the demister and the seal.

### Replacing the lower perforated plates and seals


- ▶ Loosen the screws on the solenoid valve plate.
- ▶ Remove and replace all seals with perforated plates.



*Loosen the solenoid valve plate*

Reaffix the solenoid valve plate:

- ▶ Use a dynamometric key to tighten the screws, and take care to observe the following torques:
  - 25 Nm in the case of K-MT 1-4
  - 50 Nm in the case of K-MT 6-8
- ▶ Tighten the screws crosswise in accordance with the sequence shown on the right.
- ▶ Repeat the process once.



*Correctly affixing the solenoid valve plate*

Next the new drying agent should fill up.

Fill with new drying agent and remount check valve plate



#### **Risk of falls!**

**The dryer must not be misused as a climbing aid. The components have not been designed for such loads and could fracture.**

**Only use approved climbing aids when filling the chambers.**

- ▶ Slowly fill up with new drying agent in the chamber. If necessary, use a funnel. Take special note of the next step.
- ▶ Ensure that the drying agent is filled into the chambers with a high bulk density.


**Note:**

**To achieve an optimum bulk density, we recommend using a "snowstorm" filling pipe available from the manufacturer.**

- ▶ Otherwise, tap the chamber wall with a rubber mallet while filling in the drying agent or use a stick to distribute the agent evenly inside the chamber.
- ▶ Subsequently, position the seal onto the check valve plate, align them properly and secure them.

Reaffix the check valve plate:

- ▶ Use a dynamometric key to tighten the screws, and take care to observe the following torques:
  - 25 Nm in the case of K-MT 1-4
  - 50 Nm in the case of K-MT 6-8
- ▶ Tighten the screws crosswise in accordance with the sequence shown on the right.
- ▶ Repeat the process once.



*Correctly affixing the check valve plate*

- ▶ Restart the dryer (see page 39). Check that the connection is leak tight.

## Identify and eliminate faults

The following table provides information on what designatory abbreviations are to be used for the various components. These designations are also found in the technical documentation.

Abbreviation	Component
PDI	Differential pressure gauge (only K-MT 6-8)
V1–V2 (Y2–Y1)	Main valves (solenoid valves)
V3–V4 (Y3–Y4)	Expansion valves (solenoid valves)
RV1–RV2	Check valves
RV3–RV4	Check valves of regeneration gas return line (optional)

## Summary of faults

There are different fault types. In the case of most electrically caused faults (e.g. short circuit, defective fuse, etc.) the expansion valve closes and the regeneration is interrupted. In the case of some process faults, the dryer will continue to operate for some time. Other faults on the dryer become noticeable e.g. due to unusual noises and ran pressures.

The following table shows who is allowed to remedy a fault: the owner's specialist personnel or the manufacturer's service engineer.

## Table of possible faults

Fault	Possible cause	Remedy	Specialised personnel	Service technician
No pressure build-up	The compressed pressure system upstream from the dryer is not pressurised.	Check whether the compressed pressure system upstream from the dryer is pressurised. Eliminate any faults in the compressed air system.	●	
Excessive compressed air consumption	Leakage	Check condensate trap at the upstream filter; clean, if necessary.	●	●
Dryer cannot be switched over	Solenoid valve Y1/Y2 cannot be opened.	Check supply voltage, cable, contacts and solenoid; replace, if necessary.	●	●
	Solenoid valve Y1/Y2 cannot be opened properly (audible humming sound or valve flapping).	Check supply voltage. Check spring and solenoid; replace, if necessary.	●	●
	Control board defective.	Check fuse in supply line and in the switchbox; replace, if necessary.	●	●
	Power supply interrupted, cable broken.	Reconnect the unit to the power supply.	●	
	Compressor might be off.	Check compressor synchronisation circuit.		
	Error in control programme.	Restart programme.		●
No expansion	Solenoid valve Y3/Y4 cannot be opened.	Check supply voltage, cable, contacts and solenoid; replace, if necessary.	●	●
	Solenoid valve Y3/Y4 cannot be opened properly (audible humming sound or valve flapping).	Check supply voltage. Check spring and solenoid; replace, if necessary. Check solenoid valve for contamination; clean or replace, if necessary.	●	●
Dryer is continuously bled	Solenoid valve Y3/Y4 cannot be closed properly (audible humming sound or valve flapping).	Check supply voltage. Check spring and solenoid; replace, if necessary. Check diaphragm; replace, if necessary.	●	●
Dryer is excessively bled	Solenoid valve Y1/Y2 cannot be closed.	Check solenoid and diaphragm; replace, if necessary.	●	●

## With dewpoint-sensing control (optional)

Fault code	Description of fault	Possible cause	Remedy	Specialised personnel	Service technician
+20	Upper measuring range limit exceeded	Drying capacity exceeded.	See instructions for commissioning. If the drying agent is wet, replace it.	●	
999	Dewpoint sensor defective	Error in programme.	Restart programme.		●
sens or -999	Sensor defective or irreversibly contaminated.	Sensor, sensor cable or sensor adapter defective.	Replace sensor.	●	●
SEr	Sensor not powered, or cable or sensor defective	The display appears after every 8000 operating hours.	Visual inspection; check power supply (24 V to terminals 4 and 6). Replace defective component(s).  Inform the manufacturer's service staff and order the appropriate service kit. The package includes a dongle with which you can reset the operating hours counter after maintenance has been carried out. For instructions on how to use the dongle see the enclosed information sheet (in the service kit).	●	●

# Index

## A

Abbreviation	
components	53
Address, manufacturer	6
Adsorption, explanation	16
Air ejection, sudden	10
Auxiliary heater	18

## B

Bolt connections	24
Build no.	61
Bypass line	18, 25

## C

Changing cycle mode	
explanation	34
Compressed air	11, 16
Compressor synchronisation	19
option	19
Compressor synchronisation line	
installation	26
Condensate trap	
maintenance interval	41
Connection lines	25
Connector	
electrical	26
Consumables	6
Control	
dewpoint-sensing	19
Control box	15
Control system	
pneumatic	19
signalling contacts	19
Conversions	11
Cycle	
fixed	19
variable	19
Cycle mode change	
explanation	34

## D

Danger notes	
Danger!	8
Date of manufacture	3
Dehumidification	
explanation	17
Demister	
maintenance	51

## Design

paint compatible	19
Detour line	see bypass line
Dewpoint-sensing control	19
Differential pressure gauge	15, 31
Digital display	
explanation	31
Documentation, technical	59
Dongle	
use	42
Dryer	
maintenance interval	41
Drying agent	
charging	19
handling	11
maintenance interval	41
service life	50
storage	23
Dust generation	11, 50
Dust mask	11

## E

Ear protection	13, 32
Example for installation	25
Expansion, explanation	17
Eye protection	11

## F

Fabrication no.	3
Factory settings	13
Filter	
maintenance interval	41
Fixed cycle	19
Flow diagram	64
Fluid group	60

## H

Hazard areas	10
Humidity	60

## I

Installation	
floor-mounted	22, 65
wall-mounted	22, 66
Installation area	21
Installation example	25
Installation site, requirements	21

**L**

LEDs	
explanation .....	30
Liability .....	7
Limits, permissible .....	13, 32

**M**

Machine damage, prevention .....	9
Machine passport .....	3
Mains voltage .....	60
Maintenance	
check valves .....	47
differential pressure .....	43
Muffler .....	44
replacement of filter element .....	44
sensor .....	46
solenoid valves .....	47
Maintenance contract .....	40
Maintenance interval	
condensate trap .....	43
Media	
aggressive .....	7
Misuse .....	11
Misuse, suspected .....	11
Modifications on the dryer .....	11
Muffler	
maintenance interval .....	41

**N**

Noise level .....	60
Notes	
safe, efficient handling .....	8

**O**

On/Off switch	
explanation .....	29
ON/OFF switch .....	15
Operating instructions .....	7
safe place .....	8
safety notes .....	9
target group .....	8
Operating overpressure	
minimum, maximum .....	60
Operating pressure .....	33
permissible .....	3
safety device .....	24
Operating signalling contact	
installation .....	27
Operation signalling	
contact .....	19
Options .....	67
Original replacement parts .....	13, 40

Outside installation .....	18
Overpressure, hazard .....	10

**P**

Packaging .....	20
Parameters	
preset .....	7
Perforated plate	
maintenance .....	51
perforated plates	
maintenance interval .....	41
Perforated plates	
maintenance interval .....	41
Personnel qualification .....	7, 9, 11
Pressure build-up	
explanation .....	17
sudden .....	33
Pressure Conditions .....	38
Pressure vessel .....	40
Programme	
sequence, steps .....	62
Protection class .....	60

**R**

Regeneration, explanation .....	16
Regulations for accident prevention .....	20, 21
Repairs, telephone number .....	6
Replacement parts .....	13, 40
Risk of skidding .....	10

**S**

Safety notes .....	9
general .....	11
operating phases .....	12
Warning! .....	8
Safety valves .....	24, 28
Seals	
maintenance .....	49, 51
maintenance interval .....	41
Sensor	
maintenance interval .....	41
Service, telephone number .....	6
Shutdown valves .....	25
Shutting down .....	38
Signalling lines	
external .....	26
Snowstorm filling pipe	
charging drying agent .....	52
Solenoid valves .....	15
Specialist personnel .....	8, 24
Standard equipment .....	7
Start-up device .....	18
Start-up, requirements .....	28

---

Storage room requirements .....	23
Supply cable, electrical.....	26
Supply lines.....	24

---

**T**

Target group.....	8
Temperature, ambient minimum, maximum .....	60
Transport damage.....	20
Type plate .....	9

---

**U**

Use, intended.....	11
Use, safe.....	8

---

**V**

Valves maintenance interval .....	41
Variable cycle.....	19
Vibration dampers .....	22
Visual inspection .....	42
Voltage electrical .....	25
Voltage, electrical .....	10

---

**W**

Warranty.....	7
Waste code numbers .....	14

## Annex with technical documentation

This annex comprises the following information and technical documentation:

- Technical data
- Replacement and wear parts list
- Logic control diagram
- Flow diagram
- Dimensional drawing

## Technical data

	Capacity*	Length	Height	Width	Weight	Drying agent per vessel
Type	m <sup>3</sup> /h	mm	mm	mm	kg	kg
<b>K-MT 1</b>	8	312	390	210	9	0.8
<b>K-MT 2</b>	15	312	565	210	13	1.6
<b>K-MT 3</b>	25	312	815	210	17	2.6
<b>K-MT 4</b>	35	312	1065	210	24	3.7
<b>K-MT 6</b>	56	436	1185	300	52	6.2
<b>K-MT 7</b>	72	436	1410	300	65	7.8
<b>K-MT 8</b>	86	436	1610	300	77	9.1

\* relative to 1 bar (abs.) and 20 °C (68 °F) at 7 bar operating pressure and a feed temperature of 35 °C (95 °F).

<b>Type K-MT 1–8</b>	
Fluid group (acc. to 97/23/EC)	2
max. operating overpressure	16 bar
min. operating overpressure	5 bar
min. ambient temperature	≥+1 °C (33,8 °F)
max. ambient temperature	≤+50 °C (122 °F)
Rel. humidity	≤ 60 %
Noise level : +3 dB (A) relative to free field measurement, 1 m surr. field	65 – 86 dB(A)
Mains voltage	(see type plate)
Protection class	IP 54

## Replacement and wear parts list

### Note:

When exchange or replacement parts are ordered, always state the dryer type and the build no. of the dryer. These data are found on the type plate.

### Service-kits


Service kits			
Type	Service kit	Matchcode	Order no.
K-MT 1–K-MT 8	Service kit for 12 months	K-MT12A	921210001012
	Service kit for 24 months	K-MT24A	921210001024
K-MT 1–K-MT 4	Service kit for 48 months	K-MT48A	921210001048
K-MT 6–K-MT 8	Service kit for 48 months	K-MT48B	921210003048

The service kits do not include filter elements or mufflers.


Drying agent kits								
Type	Order no.	K-MT 1	K-MT 2	K-MT 3	K-MT 4	K-MT 6	K-MT 7	K-MT 8
DESPAC1MS	921000000101	1x	2x	1x		1x		
DESPAC4MS	921000000401			1x	2x	3x	4x	1x
DESPAC15MS	921000001501							2x

# Logic control diagram


## Adsorption in B1 and regeneration in B2



### Regeneration in B1 and adsorption in B2



# Flow diagram




Pos.	Designation
10	Check valve plate
10.101	Seal
10.102	Perforated plate
10.107	Demister, left
10.108	Demister, right
10.109	Left perforated plate
10.110	Conical pressure spring
10.111	Right perforated plate
50	Regeneration gas orifice plate


Pos.	Designation
60	Control unit
70	Control system
80	Upstream filter
90	Downstream filter
100	Muffler
*	Optional devices:
110	Start-up device
120	Regeneration gas return line
701	Dewpoint-sensing unit

# Dimensional drawing

## Installation on floor



### Installation on wall



Dimension	K-MT								
	1	2	3	4	6	7	8		
A	312				436				
B	210				300				
B1	210				244				
C	395	570	820	1070	1190	1415	1615		
C1	281	536	786	1039	1121	1346	1546		
D	381	556	806	1056	1102	1327	1527		
D1	154	329	579	829	779	976	1176		
E	242				332				
F	120				210				
K	101				109				
K1	91				109				
<b>Connection</b>									
Inlet	1/4"				3/8"				1/2"
Outlet	1/4"				3/8"				1/2"

## Optional devices

